




MX-PRO Exterior Description




➤ How to place Banknotes onto Hopper ➡



- ➊ Remove paper clip, rubber band, damage bills. Align banknotes nicely on each edge. Place them on Note hopper.
- ➋ Adjust Note guides to the dimensions of your banknotes.

➤ How to open rear door for bill path access ➡

- Insert your fingers inside the tab / door lever and lift up the cover towards you. Remove jam bill or perform cleaning Using soft microfiber and brush (provided).
- Lift up and press gently to close the cover.



➤ Know important keys on Control Panel

DETAIL	Detail count results	CUR	Change currency-type	Manual Start / Confirm CLEAR / EXIT
MENU	Main Menu (User Menu)	ADD	Accumulation count	
PRINT	Print counting results to a printer	MODE	Change of Counting Modes	
SPEED	Change counting speed	BATCH	Set up various batch setting	

➤ Know Important Icons on Touch Screen:

Touch Screen Icons	Descriptions / Functions
MODE	This icon prompt mode screen where user can deactivate / active modes using slider. Save the setting by pressing Enter Icon.
MENU	This icon prompts User Menu screen
BATCH	This icon prompts Batch/Strap setting screen for Qty, Amount or DB
	Automatic or Manual Start. Light up → ON (default). Gray → OFF → press [START]
CF	Counterfeit Detection. RED LEDs → ON. No RED LEDs → OFF
	ADD (Accumulation). Light up → ON, Gray out → OFF
	Change Counting speed (800 / 1000 /1200)
	Flag represents the country's currency selected (USD default). Press to select Canadian or Multi-currencies.

➤ How to switch to different counting modes?


MODE Press [MODE] key on the Control Panel to switch from MIX → SINGLE → SORT → FACE → ORIENT → COUNT ↔


➤ How to switch to Manual Start from AUTO Start





Touch this Icon on the Touch display screen to change from automatic start of counting (Default) to Manual Start where MX-PRO will start counting when [START/ENTER] key on the control panel is pressed. Icon lights up means, it is activated whereas gray out means deactivated.

➤ How to select Multi-currency Counting operation (USD, Canada software is standard)

USD currency is default software. Touch  country flag on the touch screen to prompt currency selection screen. **AUTO** (first currency as standard) and **MULTI** (Process mixture currencies in single pass). If **MULTI** is selected and processed, Press **[DETAIL]** key or right arrow Icon to see count results of all currency- type counted and denomination breakdown.




BATCH ↓ How to set up "Denomination Batch / DB"?

● MX-2S allows users to Batch / Strap by setting individual Qty or **specific Amount (\$)** for each and every **denominations and MX-2S will stop at the Strap limit set.** Apply to **SINGLE** and **SORT** mode. Press **[BATCH]** key or  Icon to prompt batch setting screen. Press **DB** and set up your strap limit by typing dollar amount of qty for each denom. Save by pressing  icon.



How to activate ADD and CF (Counterfeit detection)

ADD **ADD** function provides cumulative count of continuous operation (multiple stack of banknotes) and it is turned OFF by default. To turn it ON, press **[ADD]** key or  Icon on the touch screen. Icon lights up indicating activation and Gray out indicates deactivation.

CF (Counterfeit detection) detects suspect banknotes using various counterfeit detectors. It is turned ON (RED Dot LEDs) by default. It is not recommended to turn it OFF. To turn off, keep pressing this Icon until all RED LEDs disappear.

➤ Important Counting Modes and explanation:

MIX **MIX (As Default Mode)**

In MIX mode, MX-PRO will denominate mixture denomination of banknotes and show Pcs, Total and breakdown → print receipt.

SINGLE **SINGLE (Stranger Mode)**

MX-PRO counts and delivers first detected genuine banknotes as standard to Stacker and deliver other denominations to Reject Pocket. DB strapping function is available in this mode.


SORT **SORT (Count, Separate, Strap)**


MX-PRO processes organized or mixture denominations strap while stopping at a new denomination change. DB strapping is available.

FACE **ORIENT** **FACE (Front / Back), ORIENT (Direction)**

MS-PRO processes first detected same Face or same portrait direction of banknote for the denomination and reject non-faced (wrong face) or non-oriented (wrong portrait direction) banknotes of the same denomination to the Reject Pocket. Remove all from Reject pocket and align them with banknotes in the Stacker w/same face / portrait.

BATCH ↓ How to Batch by Qty or by Amount (\$) ?

● MX-PRO allows users to Batch / Strap by a **specific Qty** or by **specific Amount (\$)**. Press **[BATCH]** key or  Icon on the touch screen to prompt batch setting screen by QTY, AMOUNT.




REJECT: 123
\$ 999

Enter PCS by using numeric key pad; → to confirm; → EXIT to Main Screen.

REJECT: 23
\$ 123

Enter \$ AMOUNT by using numeric key pad; → to confirm; → EXIT KEY TO return.

How to deactivate counting Modes (Simplicity)

● Users can deactivate counting modes not needed for their operation and for simplicity. Press Mode Icon on the touch screen and use slider to disable the modes users do not need. Enter  or press **[START]** key on control panel to confirm and press EXIT key to return to Main Screen.

